



M² transformation module for high power laser material processing of flat panels/ wafers

The operating principle of the M^2 transformation module is to recombine an input beam with a large and symmetrical M^2 into a highly asymmetrical M2 output beam. This output beam will have a much smaller M^2 (~2) in the first (fast) axis and a very large M^2 in the second orthogonal (slow) axis. The transformation occurs continuously along the module length to achieve a very high transformation precision.



How it works:

The incident multimode laser beam with beam quality factor M_x^2 , M_y^2 for axes X, Y is divided into N discrete sections. The module modifies the beam quality factor so that the output M2 of each axis becomes $M_x^2 \cdot N$, M_y^2/N of the original values.

Tel +972-8-940-9687 www.holoor.com Fax +972-8-940-9606 holoor@holoor.co.il **本平貿易株式会社** TAIHEI BOEKI CO., LTD. 開発営業課 T103-0023 東京都中央区日本橋本町2-2-2

〒103-0023 東京都中央区日本橋本町2-2-2 TEL 03-3270-4826 FAX 03-3245-1767 http://www.taiheiboeki.co.jp tokyo@taiheiboeki.co.jp

PO BOX 1051, Rechovot 76114



Why choose an M² transformation module for your system:

- The module has a low sensitivity to positioning tolerances and is very easy and fast to align
- The module has a low sensitivity to the dimensions of the incident beam size and can work with both • round and elliptical beams.
- Extremely high precision of transformation, achieved by a lithographical production process.
- The module has an extremely small thermal lensing effect. This is because the Fused Silica DOE has a much smaller thermal coefficient than a refractive element.
- The Laser damage threshold of the M^2 module is high due to the large incident beam diameter, the high • efficiency DOE and low NA of the optics.
- Holo/Or also has a solution to use several input lasers simultaneously\ with very few alignment procedures, or supply it as pre-aligned modules.

Specifications of the W1 module W12-002-1.	
Wavelength:	343 nm
Input M ²	<25
Output M ² for fast axis	2-3
Input beam size	5-5.5
Output beam size	~0.8x12 mm
Overall Efficiency	~95%
Dimensions	~505 x 40.6 x 40.6 mm
Optical elements material	UV grade Fused Silica

Specifications of the M^2 Module $M_{2-002-1}$.

Special features:

- Adjustment of output beam orientation by adjusting 2 rotator rings
- Opto-mechanical cage compatibility
- Assembled in clean room environment

Applications

Laser annealing to improve process quality in a variety of industries:

- Lift off process for manufacturing flexible displays
- OLED displays •
- Semiconductor devices
- Thin-film solar cell production •
- Sensor production

Materials

Processing of a broad range of materials including:

- Silicon •
- Silicon on glass
- Polymers

Tel +972-8-940-9687 www.holoor.com Fax +972-8-940-9606 holoor@holoor.co.il

PO BOX 1051, Rechovot 76114



〒103-0023 東京都中央区日本橋本町2-2-2 TEL 03-3270-4826 FAX 03-3245-1767 http://www.taiheiboeki.co.jp tokyo@taiheiboeki.co.jp



Tel +972-8-940-9687 Fax +972-8-940-9606 www.holoor.com holoor@holoor.co.il

PO BOX 1051, Rechovot 76114



7103-0023 東京都中央区日本橋本町2-2-2 TEL 03-3270-4826 FAX 03-3245-1767 http://www.taiheiboeki.co.jp tokyo@taiheiboeki.co.jp